



38-39/6-044

Ill. No.	Part No.	DESCRIPTION	Qty.	Change Point	REMARKS
VENTILATION					
1	CZH 1318	Nozzle—air intake—LH	1		
2	AB 608041	Screw—nozzle	3		
3	WA 702101	Washer—plain	3		
4	AXE 199	Hose—air intake	1		
5	AXE 185	Hose—inner	1		
6	FNZ 103	Nut—clip—hose	1		
7	WE 702101	Washer—spring	1		
8	AXE 630	Clip—hose	1		
9	AXE 336	Screw—demister	4		
10	AXE 32	Demister—LH	1		
	AXE 33	Demister—RH	1		
11	AXE 196	Hose—demister	2		
12	AXE 41	Screw	8		
13	WL 700101	Washer—spring	8		
14	AXE 30	Vent—LH	1] 1001 &] 1300] 1000 &] Minimatic
	AXE 31	Vent—RH	1		
14	AXE 603	Vent—LH	1		
	AXE 604	Vent—RH	1		
	CZH 659	Binnacle—face vent—LH	1		
	CZH 658	Binnacle—face vent—RH	1		
15	ALA 6292	Gasket—vent	2		
16	AXE 183	Clip—hose—LH	1		
17	AXE 197	Hose—flexible—RH	1		
18	CZH 694	Gasket—nozzle	1		
19	AXE 184	Nozzle—vent	1		
20	AXE 631	Clip—hose	1		
21	WE 702101	Washer—spring	1		
22	FNZ 103	Nut—clip	1		
23	AXE 182	Box—distribution	1		
24	CZH 700	Hose	1		
25	CZH 1717	Gasket—box	1		
26	WE 702101	Washer—spring	4		
27	FNZ 103	Nut	4		
28	AXE 198	Hose—flexible	1		