



38-39/6-007

Ill. No.	Part No.	DESCRIPTION	Qty.	Change Point	REMARKS
<b>WATER PUMP AND FAN</b>					
	GWP 102	PUMP ASSEMBLY—WATER	1		
2	12G 1773	Vane—water pump	1		
3	88G 446	Seal	1		
5	2A 778	Wire—locating	1		
6	8G 733	Hub—pulley	1		
7	88G 215	Gasket—pump	1		
8	88G 618	Adaptor	1		
	8G 2675	Kit—repair—water pump	1		
9	12G 2077	Dowel	2		
10	HZS 0515	Bolt—long	2		
11	HZS 0510	Bolt—short	2		
12	LWZ 305	Washer—spring	4		
13	2A 601	Pulley—fan and pump	1		
14	12G 2129	Fan—11 blade	1		
15	SH 604061	Bolt—fan	4		
16	LWN 204	Washer—spring	4		
17	2A 940	Pulley—crankshaft	1		Minimatic
17	88G 305	Pulley—crankshaft	1		1300, 1000 & 1001
18	AEA 312	Bolt—pulley	1		
19	12A 398	Washer—lock	1		
20	GFB 102	Belt—fan	1		
21	17D 11	Fan—dynamo	1		
22	12A 1772	Pulley—dynamo	1		1000 & Minimatic
23	2A 497	Link—dynamo adjuster	1		
24	2A 128	Pillar—link	1		1000, 1001 & Minimatic
	12G 289	Pillar—link	1		1300
25	FNZ 106	Nut	1		
26	LWZ 306	Washer—spring	1		
27	ZCS 0505	Screw	1		
28	LWZ 305	Washer—spring	1		
29	LNZ 206	Nut	1		
30	LWZ 306	Washer—spring	1		
31	PWZ 306	Washer—plain	1		
32	12A 526	Bracket—support—dynamo	1		
33	HZS 0507	Screw—bracket	2		
34	LWZ 305	Washer—spring	2		
35	AXE 83	Screw	1		
36	PWZ 305	Washer—plain	1		
37	LWZ 305	Washer—spring	1		1000 & Minimatic
38	LNZ 205	Nut	1		
39	HBZ 0514	Bolt	1		
40	LNZ 205	Nut	1		
41	LWZ 305	Washer—spring	1		
42	PWZ 305	Washer—plain	1		