



Ill. No.	Part No.	DESCRIPTION	Qty.	Change Point	REMARKS
HAND BRAKE CABLE AND LEVER					
	21A 2681	LEVER ASSEMBLY—HAND BRAKE	1		
2	21A 907	Knob—release	1		
3	13H 4217	Washer—Starlock	1		
4	21G 5042	Washer—anti-rattle (felt)	1		
5	2K 8848	Spring	1		
6	ACA 5417	Washer—plain	1		
7	21A 908	Rod—release §	1		
8	ACA 5336	Pawl	1		
9	CRS 0306	Rivet	1		
10	21A 2130	Rivet—pawl to pivot	1		
11	PWZ 103	Washer—plain	1		
12	AXE 684	Rivet	1		
13	21A 2688	Washer	1		
15	ACA 5521	Washer—trunnion §	2		
16	21A 906	Washer—trunnion §	2		
17	21A 2155	Trunnion—lever to cable §	1		
18	21A 2685	Ratchet	1		
19	HZS 0506	Screw	2		
20	WL 600051	Washer—spring	2		
21	NH 605041	Nut	2		
22	2A 5858	Nut—adjusting	2		
23	PWZ 104	Washer—plain	4		
24	ACH 8508	Spring—adjusting	2		
25	ACA 5522	Fair lead—cable	4		
26	21A 385	Pad—sealing—cable	4		
27	PMZ 0312	Screw	4		
28	LWZ 203	Washer—spring	4		
29	FNZ 103	Nut	4		
30	21A 2454	Sector—hand brake cable	2		
31	CLZ 0549	Trunnion	2		
32	AWZ 105	Washer—plain	2		
33	AXE 687	Pin—split	2		
34	21A 2224	Cable—hand brake	2		
35	CLZ 0409	Pin—clevis	2		
36	AXE 688	Pin—split	2		