



| Ill. No.            | Part No. | DESCRIPTION                    | Qty. | Change Point | REMARKS              |
|---------------------|----------|--------------------------------|------|--------------|----------------------|
| <b>DIFFERENTIAL</b> |          |                                |      |              |                      |
| 11                  | ZCS 0508 | Screw—cover                    | 10   |              |                      |
| 12                  | LWZ 305  | Washer—spring                  | 10   |              |                      |
| 13                  | 2A 3535  | Shim—bearing—0.0508 mm         | A/R  |              |                      |
| 13                  | 2A 3534  | Shim—bearing—0.0762 mm         | A/R  |              |                      |
| 14                  | 13H 5305 | Bearing—ball                   | 2    |              |                      |
| 15                  | 22A 411  | GEAR ASSEMBLY—DRIVE (62 TEETH) | 1    |              | 1300                 |
| 15                  | 22A 401  | GEAR ASSEMBLY—DRIVE (64 TEETH) | 1    |              | 1000 & 1001          |
| 15                  | 22A 1003 | GEAR ASSEMBLY—DRIVE (72 TEETH) | 1    |              | Minimatic            |
| 16                  | ATA 7378 | Bush                           | 1    |              |                      |
| 17                  | ATA 7232 | Bolt—gear to differential case | 6    |              |                      |
| 18                  | ATA 7385 | Washer—tab                     | 3    |              |                      |
| 19                  | BTA 101  | Washer—thrust gear             | 2    |              |                      |
| 20                  | RPS 1418 | Peg—pin                        | 1    |              |                      |
| 21                  | BTA 154  | Block—thrust                   | 1    |              |                      |
| 22                  | 2A 7062  | Washer—thrust—pinion           | 2    |              |                      |
| 23                  | 2A 7015  | Pinion—differential            | 2    |              |                      |
| 24                  | BTA 166  | Pin—pinion centre              | 1    |              |                      |
| 25                  | BTA 145  | CASE ASSEMBLY—DIFFERENTIAL     | 1    |              |                      |
| 26                  | ATA 7378 | Bush                           | 1    |              |                      |
| 8                   | 22A 1611 | Gasket—end cover               | 2    |              | 1000, 1001 &<br>1300 |
| 8                   | 22A 1612 | Gasket—end cover               | 2    |              | Minimatic            |



